

MALLORY MARINE 2010 CATALOG

THE MALLORY MARINE PART NUMBER SYSTEM

Mallory Marine part numbers consist of 6 digits and are grouped by product classification.

Typical part number:

9-1 0000
↑ ↑ ↑
A B C

- A. The first digit for Mallory Marine is a 9-, this is an internal identifier that indicates this is a Marine product.
- B. The second digit indicates the product classification of the part. The classification list is as follows:

1 = battery cables & accessories	
1 = electrical system products	
2 = ignition system products	
3 = fuel system products	
4 = cooling system products	
5 = engine system products	
6 = gaskets, gasket sets	
7 = drive system products	
8 = oil & lubricants	
9 = to be announced	

- C. The last four digits are unique for each product and in many cases the third digit will be related to a specific OEM.

We hope this will assist you to quickly learn and understand our new part numbers so using Mallory Marine Products will be easier than ever.



TABLE OF CONTENTS

ACCESSORIES / MISCELLANEOUS PAGE

Apparel	4-5
Cable Ties & Cable Tie Tools	10
Service Manuals	6-9
Service Tools	10
Test Equipment	14

OILS & LUBRICANTS PAGE

Engine Oil, TC-W3 Two Cycle	11
Engine Oil, FC-W 4-Stroke	11
Fuel Stabilizer	13
Fogging Oil	13
Gear Lube	12
Gear Lube Pumps	13-14
Grease Guns	13
Oil Absorbent Pads	14

BATTERY CABLES & ACCESSORIES PAGE

Cable, Bulk Reels	15
Cable Assemblies	15

OUTBOARD ELECTRICAL PARTS PAGE

Alternators	28
Emergency Cut-off Switch	17
PWC Starters	16
Key Switch	17
Relays	18
Rectifiers	28
Solenoids	17-18
Starters	24-25
Stators	44
Trim Motors & Pumps	30-32
Valve Body, trim pump	30-32
Voltage Regulators	28

OUTBOARD IGNITION PARTS PAGE

Contact Sets	34
Condensers	34
Emergency Cut-off Switch	17
Ignition Coils	36-37
Ignition Switch	17
Powerpacks	40-41
Spark Plug Leads	33-34
Stators	44
Switchboxes	43
Tune-Up Kits	34

OUTBOARD FUEL SYSTEM PARTS PAGE

Carburetor Kits	52-62
Carburetor Floats	53, 56
Fuel Connectors	47
Fuel Filters	48-51
Fuel Pumps	65
Fuel Pump Repair Kits	63, 65
Hose Barbs	47
Needle Valves & Seats	53, 56
O2 Sensors	65
Throttle Position Indicator	65

OUTBOARD COOLING SYSTEM PARTS PAGE

Grommets	74
Impellers	69-71
Impellers Keys	74, 76
Motor Flushing device	66
Thermostats	66
Thermostat Kits	66
Water Pump Bases	75
Water Pump Housings	72, 77
Water Pump Cups	72
Water Pump Wear Plates	72
Water Pump Kits	73, 75-78
Water Tube Guide	74
Wear Plates	72

OUTBOARD INTERNAL ENGINE PARTS PAGE

Air Filter	88
Bearings, wrist pin	90-91
Bearings, connecting rod	90-91
Bearings, main	90-91
Connecting Rods	92
Circlips	95-101
O-Rings	102-103
Oil Filters	88
Oil Seal	102-103
Pistons	93-101
Piston Rings	95-101
Rod Bolts	92

OUTBOARD GASKETS & GASKET SETS PAGE

Air Box Gaskets	108, 116-117
Base Gaskets	110, 117-118
Carburetor Gaskets	104, 108, 116, 126
Drain Plug Gaskets	111, 119, 123-124, 126
Divider Plate Gaskets	110, 117
Exhaust Gaskets	109, 117
Fuel Pump Gaskets	108, 116,
Head Gaskets	104, 107, 116, 123-125
Impeller Gaskets	111, 118-119, 126
Intake Gaskets	108-109, 116-117
O-Ring, Cylinder Head	107, 116
O2 Sensor Gasket Kit	126
Powerhead Gasket Sets	105-127
Reed Block Gaskets	109, 116-117
Shift Cover Gaskets	111
Valve Stem Seals	107, 126
Thermostat Gaskets	110, 117, 126
Water Jacket Gaskets	109, 117

OUTBOARD LOWER UNIT PARTS PAGE

Bearings	144
Bearing Carriers	150,
Bushing, Shift Shaft	148, 149
Control Box Parts	130
Cotter Pins	151
Drain/Fill Screws	149
Gear Sets	145-147
Oil Seals	139-140
O-Rings	141-143
Pinion Nut	148
Prop Nuts	151
Prop Nut Kits	150-151
Prop Shaft	148
Prop Spacers	151-152
Seal Kits	130-135
Spanner Nuts	149
Stainless Steel Locknuts	148
Tab Washers	150-151
Trim Hoses	148
Washer, Pinion Nut	148

INBOARD & STERNDRIVE ELECTRICAL PARTS PAGE

Alternators	162-163
Circuit Breakers	154
Relays	153-154
Reservoirs, Power Trim	167-168
Solenoids	153
Starters	158
Trim Motors & Pumps	167-168

TABLE OF CONTENTS

INBOARD & STERNDRIVE IGNITION PARTS

	PAGE
Condensers	.169
Contact Sets	.169
Ignition Coils	.181-183
Ignition Modules	.183
Ignition System, Complete	.195
Distributor Caps	.173-174
Distributors	.196-199
Distributor Gears	.198
Electronic Conversion Kits	.184
Rotors	.169-171
Sensors, Ignition	.183
Shift Assist Modules	.185
Spark Plug Wire Sets	.186-194
Tune-Up Kits	.171-172
Wire Markers	.185
Wire Separators	.185

INBOARD & STERNDRIVE FUEL SYSTEM PARTS

	PAGE
Carburetor Kits	.204-207
Carburetor Adapter Flange Kit	.218
Carburetor Choke Thermostats	.207
Carburetor Floats	.207
Carburetor Needle & Seat	.207
Carburetors, New	.214-218
Carburetors, Remanufactured	.219
Coolant & Temp Sensors	.223,000
EFI throttle body kit	.228
EFI Multi-Port System	.227
Flame Arrestors	.213
Fuel Filters & Kits	.200-203
Fuel Injectors & Kits	.221
Fuel Pressure Regulators	.222
Fuel Pumps	.229-235
IAC Motors	.222
Knock Sensors	.223
MAP Sensors	.222-223
Throttle Position Sensors	.222
Water Separating Filters	.200-203

INBOARD & STERNDRIVE COOLING SYSTEM PARTS

	PAGE
Base, Water Pump	.271
Cup, Water Pump Housing	.272
Drain Cock	.284
Drain Elbow	.284
Exhaust Flapper	.284
Hose Clamp	.286
Hose Kits	.284-286
Hose, Circulating Pump	.284-285
Housings, Water Pump	.271-272
Impellers	.270-271
Impeller Kits	.270-271
Manifolds & Accessories	.240-268
Temp Senders	.286
Thermostats	.275-276
Thermostat Housings	.283
Thermostat Kits	.276
Water Pump, Engine Circulating	.269
Water Pump Kits	.271

INBOARD & STERNDRIVE ENGINE PARTS

	PAGE
Air Filters	.290
Belts	.292
Crankcase Filters	.290
Cylinder Heads, New	.291
Engine Couplers - see drive parts	.310
Engine Primer	.293
Freeze Plug Kits	.293
Mount, engine	.293
Oil Filters	.287-288
Valve Covers	.291

INBOARD & STERNDRIVE GASKETS & GASKET SETS

	PAGE
Carb Mounting Gaskets	.294-295
Circulation Pump Gaskets	.295
Cylinder Head Gaskets	.296-297
Exhaust Gaskets & Sets	.297-299
Fuel Pump Gaskets	.295
Intake Gaskets & Sets	.299-300
Gasket Sets, Overhaul	.297
Oil Pan Gaskets & Sets	.301
Outdrive Mounting Gasket Sets	.296
Thermostat Gaskets	.294
Valve Cover Gaskets	.300-301
Water Pump Gaskets	.295

INBOARD & STERNDRIVE DRIVE SYSTEM PARTS

	PAGE
Anchor Pin Kits	.316
Ball Gears & Kits	.317
Bearings	.312-312, 315
Bellows	.305-307
Bellows Kits	.305-306
Bushings, Pivot Pin	.316
Bushings, Shift Shaft	.315
Center Socket	.311
Check Valve Kit	.313
Drain/Fill Screw	.318
Drive Shafts	.314
Electric Shift Cable	.309
Engine Couplers	.310
Exhaust Tubes	.307
Gear Housings, Lower	.314, 317
Gear Housings, Upper	.312
Gear Repair Kits	.312, 314
Gimbal Bearings	.311
Hose, Water Intake	.305-306
Oil Seals	.332-333
O-Rings	.334-337
Pinion Nut	.314
Prop Shafts	.314
Prop Nut	.318
Prop Nut Kits	.318
Prop Spacer	.318
Ring, Upper Unit Spacer	.312
Seal Kits	.319
Shift Arm	.309
Shift Cable	.308-309
Shift Cable Kits	.308
Shift Cable Slide	.309
Shift Shafts	.314
Shift Shaft Bushings	.315
Shift Slide Screw	.309
Spanner Nut	.312
Stainless Steel Lock Nut	.317
Tab Washer	.316, 318
Top Cover	.312
Trailer Clips	.318
Transom Seal	.306
Transom Seal Kits	.305-306
Trim Bushings	.316-317
Trim Hoses	.303-304
Universal Joint	.311
Universal Joint Assembly	.311
Yokes	.311, 317

QUICK REFERENCE GUIDE

	PAGE
Inboard Carburetor to Carburetor Kit	.338-343
Holley Carburetor- P/N to Model w/CFM	.344-345
Outboard Carb to Carb Kit	.346-351
Mallory Distributor Parts Guide	.352-354
Prestolite Distributor Parts Guide	.354-355
Competitive Interchange Guide	.356-407
Part number to Page Number Guide	.408-447